VIVOTEK Mounting Accessories
AM-71B Conduit Box

Installation Guide

I Compatible VIVOTEK Cameras

Compatible cameras/brackets
A: FD9389 series, FD9368-HT, FD9388-HT
B: IT9388-HT
C: FD9360-H, FD9380-H

**Mounting Dimensions**

**Package Contents**

x3   x3   x3

II Installation

Remove the top cover.

❶

A 3/4" conduit is required for routing the cables with waterproof connection.

❷

Install the cable gland and pass cables through it.

⚠️ If using the bottom hole, seal the center hole.

OR

3/4"

❸ Attach the included alignment sticker to a preferred position. Drill holes on the wall and install the junction box. If space behind the wall allows, you may also pass cables through the wall.


**❹** Loosen and remove the camera top cover. (Using one of the supported cameras as an example)

❼ Make sure the rubber seal is properly installed to the center hole. The outer rim of the seal must be through and cover the edge of the hole.


5 ~ 6.3mm

❽ **A**: FD9389 series, FD9368-HT, FD9388-HT
**B**: IT9388-HT
C: FD9360-H, FD9380-H

❺ Pass the camera's Ethernet cable through the center hole of the box and the rubber seal.


❻ Install the waterproof components of the cable gland to your Ethernet cable following the QIG of your camera. The cable gland will be placed within the protection of the box.

5.5 ~ 6.4mm

❾ Secure the top cover by fastening 3 cross-head screws.

❿ Install the camera using the corresponding mounting holes.

11 Open a live view console and adjust the shooting direction.
Refer to the camera's QIG for more information.

Secure the camera top cover.

T10